

THE SHARPER IMAGE®

Professional Plus™ Ionic Breeze® TABLETOP™ Silent Air Purifier

SI719 Instructions

INCLUDES IMPORTANT
SAFETY INFORMATION.

READ ALL INSTRUCTIONS
BEFORE USING THIS APPLIANCE.
SAVE THESE INSTRUCTIONS.

SHARPER IMAGE DESIGN®



Warnings

WARNING: To reduce the risk of fire, electric shock or injury when using any electrical appliance, basic precautions should always be observed, including the following:

- Use indoors only.
- Unplug from outlet when not in use and before servicing.
- Use only as described in this user manual.
- Do not use if adapter or plug appears to be damaged. If the appliance is not working properly, or has been dropped, damaged, left outdoors or dropped into water, return it to a service center or to the original place of purchase.
- Do not handle the adapter or appliance with wet hands.
- Do not put any object into openings. Do not continue to use with any opening blocked. Keep all openings free of dust, lint, hair or anything that may reduce airflow.
- Keep hair, loose clothing, fingers and all parts of the body away from openings.
- Do not operate the unit in areas where flammable or combustible products or vapors may be present.

READ AND SAVE THESE INSTRUCTIONS

Frequently Asked Questions About the OzoneGuard™

Where is the OzoneGuard™?

This Ionic Breeze was packed with an OzoneGuard™ front grill already installed. To clean the OzoneGuard and the front grill, follow the directions for Thorough Cleaning of the front grill, found in this product instruction manual.

Note: The OzoneGuard cannot be detached from the front grill. The OzoneGuard has sharp edges; use caution when cleaning.

What does OzoneGuard do?

With the OzoneGuard in place, a significant portion of ground-level ozone inside the air purifier — including any trace levels of ozone by-product — is converted into oxygen before the cleaned air circulates back into the room.

Why is the OzoneGuard smaller than the grill itself?

The majority of the air output is directed toward the center of the grill and therefore a larger OzoneGuard isn't necessary.



IMPORTANT NOTE: Candles, gas heaters and other oil-burning products create soot. This soot can be distributed through a ventilation system and cause a sudden overload of soot to build up on around your Ionic Breeze. For better air quality and reduced cleaning, avoid burning candles indoors and have gas appliances checked on a regular basis.

Setup and Operation

1. Place the Ionic Breeze on a flat surface, leaving at least six inches of air space around the main housing.
2. Connect the adapter plug to the power jack at the base of the Ionic Breeze. Plug the adapter into a 110V outlet.
3. Switch the **POWER CONTROL** to the desired setting:

HIGH: Use this setting for medium or large areas.

LOW: Recommended for small and medium areas, particularly where there is limited air circulation.




Cleaning the Collection Grid

This *Professional Plus*™ model features 3 charged collection blades separated by 2 driver blades. This improves the particle capture rate.

Cleaning the grid is required every one or two weeks.

1. Before cleaning, unplug the unit.
2. Remove the collection grid by pulling it from the top of the unit.
3. Use a dry or slightly damp towel or sponge to quickly wipe the dust from each of the collection bars. Or, wash the grid under running water and allow it to dry.
4. Before replacing the grid, invert the main housing two or three times.

Beads inside the unit slide up and down, removing particle buildup from the ionizing wires and helping maintain silent operation.




Thorough Cleaning

Occasionally, or if the Ionic Breeze makes noise, a thorough cleaning of the grid and ionizing wires may be required.

1. Before cleaning, unplug the unit.
2. Remove the collection grid by pulling it from the top of the unit.
3. To unlock and remove the front grill, pull the **RELEASE-TAB**.
4. Use the included brush to wash the grill and grid with warm soapy water. Rinse and allow to dry for 24 hours before returning to unit.
5. Using a hair dryer or compressed air, blow air to remove any accumulated particles from the ionizing wires and interior of the main housing.

Note: Because of debris from the blowing air, it is advisable to do this outdoors.



Additional Information

The exterior of the unit can be cleaned using a cloth or sponge and a solution of one part household bleach to five parts water or any bleach-based cleaning spray for household use.

Allow the surface to dry completely before plugging it back into an outlet.

IMPORTANT: For better air quality and reduced cleaning, avoid burning candles and have gas appliances checked on a regular basis. Soot produced by burning oil-based products will adhere to plastic and be more difficult to clean from the product.

The Ionic Breeze® air purifiers comply with current U.S. safety requirements for low ozone emissions for consumer products. We recommend that individuals with a history of respiratory disease consult with their doctor about possible heightened sensitivity to very low ozone.

Statement of FCC Compliance – Model SI719

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Statement of FCC Compliance – Model SI719

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for assistance.

One-Year Warranty

What Is Covered

This warranty covers any defects in materials or workmanship, with the exceptions stated below.

How Long Coverage Lasts

This warranty runs for one year from the date of original purchase.

What Is Not Covered

This warranty does not cover damage caused by misuse or use other than as intended and described in the product instruction manual, or loss or damage to batteries or removable parts.

What The Sharper Image Will Do

The Sharper Image warrants this product against defects in materials and workmanship. When repair is not practical, The Sharper Image will have the option to replace the defective product with a fully warranted, factory-reconditioned product that is the same or has similar functionality.

How to Obtain Service

Return the product and receipt, along with a brief explanation of the problem, to:

T.S.I. - Returns Department
2901-A West 60th Street
Little Rock, AR 72209

If you have questions please feel free to contact our customer service representatives at 1-800-344-5555 or by email at care@web.sharperimage.com.

This warranty gives you specific legal rights, and you may have other legal rights that vary from state to state.

© 2006 Sharper Image Corporation

Sharper Image Corporation
350 The Embarcadero, Sixth Floor
San Francisco, CA 94105-1218
(415) 445-6000

Shop online: **www.sharperimage.com**

Due to continuing improvements, actual product may differ slightly from the product described herein.

V1 05/06